




HK85 installation


Vension No:20130815



Contents

1 Toolings	1
2 Components	1
3 Components installation	1
Typical 1: Partition up to ceiling	1
3.1 Wall starter installation & vertical adjustment	2
3.2 Top and bottom groove installation & vertical adjustment	2-3
3.3 Corner pole installation	4
3.4 Horizontal panels connection	4-5
3.5 Vertical panels connection	6-7
3.6 Blind installation	7-8
Typical 2: Partitions not up to ceiling	9
4 Door Illustration	9
4.1 Wood swing door illustration	10-17
4.2 Glass swing door illustration	18-20
4.3 Glass sliding door illustration	21-23


1 Toolings



Electric drill



Gradienter



Allen key

2 Components

Wall starter




Ceiling connection




Bottom connection



Vertical panel




Horizontal panel




Corner pole



Blind




Top bar



3 Component installation


Typical room :

Typical 1: Partition up to ceiling




3.1 Wall starter installation & vertical adjustment


1



2




3




3.2 Top and bottom groove installation & vertical


1




2




3




4



3.3 Corner pole installation



Different corner pole




2 ways connection system

3 ways connection system



4 ways connection system

3.4 Horizontal panels connection


1



2





Section A1




Section B1

3




Section A2




Section B2

3.5 Vertical panels connection


1






2




3






1





2





3




Controlled wire :




Controller:



Note: Controller should not be fixed at the corner position.




Typical 2: Partitions not up to ceiling




Note:

1. The only difference is to use top bar instead of ceiling connection when the partitions are not up to ceiling.
2. Fix the bottom connection, then fix the first panel, then fix the top bar, finally fix the panels one by one.

① Connection between top bar and wall starter





M8*60 round head bolt
X 1




② Connection between top bar and corner pole

M8*50 round head bolt
X 2




4 Door Illustration

4.1 Wood swing door illustration




I: Door frame installation


Step 1: Up door frame installation




Remark:




Step 2: Lock side door frame installation




Remark:



Step 3: Hinge side door frame installation




Remark:




II : Door leaf installation

Remark:




Join the two hinges together to fix the door leaf.

Image :




III : Coded lock installation


Coded lock break-down :




Components list:




1: External lock




2: Internal lock




× 2
3: Plastic mat



4: Axis



5: Strike plate



6: Stopper






× 4
7: Self-tapping screw



× 2
8: Long screw







CRV-3mm
9: Allen key





How to set the codes for the coded lock?



Step 1:



Step 2:





Step 4:



IV:Door closer installation


Components list:



Door closer
X 1





Hook
X 1





Locator
X 1





screw
X 4




Fix the door closer with the door leaf



Insert the hook and locator before fixing the upper door frame.




Locator




Hook




Uplift the door leaf, and join the hinges together







Loose the screw, fix the bracket with the hook.




How to adjust the door closer?




Please do careful when adjuste the screw, the Hydraulic oil may leakage if you adjuste too much !

4.2 Glass swing door illustration




I : Door frame installation



Step 1: Up door frame installation



Step 2: Lock side door frame installation




Step 3:Hinge side door frame installation




Section


45°joining:



II: Hinge installation





plastic mat (inside and outside)




III: Lock installation

Step 1: Lock body installation




Lock for left and right





plastic mat (inside and outside)

M5*8 positioner screw
X 2




M5*8 positioner screw
X 1



M5*6 positioner screw
X 1

Step 2: Lock mat installation




M4x16 counter sunk
self-tapping screw
X 2

M4x5 counter sunk screw
X 1

4.3


Glass sliding door illustration





Note: ★ pay special attention

A bottom channel assembling

Step 1




Step 2




M4*30 counter-sunk screw with plastic insert


Step 3






B top channel assembling:




M4*30 counter-sunk screw with plastic insert



C Door frame assembling:



D: right door frame assembling:




★ : connection pole is longer than requirement cut it into right size accordingly

Cushion plastic

section


E: Lock assembling

Locking tab assembling :




★ : Attach the first half lock with barrael to the glass, then fix another half lock to it by screw

★ : the door frame is longer than required. Cut it into right size from bottom.



Step 4



Step 5